


GENERAL CHASSIS (3)

EAS20156

GENERAL CHASSIS (3)

Removing the fuel tank covers and fuel tank protector



Order	Job/Parts to remove	Q'ty	Remarks
	Fuel tank front cover/Front side panel/Front side cowling		Refer to "GENERAL CHASSIS (2)" on page 4-6.
	Passenger seat/Rider seat		Refer to "GENERAL CHASSIS (1)" on page 4-1.
	Rider seat height position adjuster		Refer to "GENERAL CHASSIS (1)" on page 4-1.
1	Fuel tank cover (left)	1	
2	Fuel tank cover (right)	1	
3	Fuel tank protector	1	